







- Overview


"Slide Pot" → potentiometer
- change resistance



- what is ADC?




- potentiometer?



R_1 & R_2 combine always has $10k\Omega$

$$V_{out} = \frac{3.3 R_2}{(R_1 + R_2)} = \frac{3.3 R_2}{10 k\Omega}$$

so V_{out} is approximately linear to R_2 .



- Steps:

- 1) build the circuit (part a)
- 2) understand software organization (part b)
- 3) Setup ADC (part c)


→ 4) convert ADC value to actual length
(part c & d)

you are
90%
done at
this point!


5) Use systick interrupt instead
(part f & g & h)

6) Check if your solution is accurate. (part i)

1) build the circuit (part a)




bottom view of slide pot:



*tips: easy to connect with female Jumper wire.

- add a ruler:



2) Software

0) All the initialization i.e. `ADC_init(); OLED_init` ...

1) get your ADC value

i.e. `int Data = ADC_In()`

2) convert raw data to Fixed point in
0.1 mm

i.e. `int position = Convert(Data);`

3) `OutFixed(Position);`

4) go back to step 1 & repeat!

In a nutshell...

a) copy all OLED function you wrote from Lab7

b) you need to write 1. `ADC_init()`

2. `ADC_In()`

3. `Convert()`

both in `ADC.C`

— directly in `main.c`


3) Set up ADC

understand the hardware

- there are 2 ADC in the chip




- where is the input?




✓ we use PD2 this time, which
aka "analog input #5" (ain5)

- how many different slide pots can TM4C support?
2? actually no... because we have sequencer!!

each ADC has 4 sequencer ...
so $2 \times 4 = 8$ slide pots max!



We only use Sequencer 3 in this Lab
"SS3"



* each sequencer will have priority,
set in Sample Sequencer Priority
hence "SSPRI"

- when to take sample
 - software trigger / GPIO / continuous
- how fast is the ADC?
125k/sec in Peripheral configuration "PC"
- averaging?
Yes 64

Sample Averaging Control → "SAC"

- Bring it all together...

We want PD2

ADC on TM4C123

```
Channel 9 is PE4
void ADC0_InitSWtriggerSeq3_Ch9(void){
    SYSCTL_RCGCGPIO_R |= 0x10; // 1) activate clock for Port E
    while((SYSCTL_PRCGPIOR&0x10) == 0){};
    GPIO_PORTE_DIR_R &= ~0x10; // 2) make PE4 input
    GPIO_PORTE_AFSEL_R |= 0x10; // 3) enable alternate fun on PE4
    GPIO_PORTE_DEN_R &= ~0x10; // 4) disable digital I/O on PE4
    GPIO_PORTE_AMSEL_R |= 0x10; // 5) enable analog fun on PE4
    SYSCTL_RCGCADC_R |= 0x01; // 6) activate ADC0
    delay = SYSCTL_RCGCADC_R; // extra time to stabilize
    delay = SYSCTL_RCGCADC_R; // extra time to stabilize
    delay = SYSCTL_RCGCADC_R; // extra time to stabilize
    delay = SYSCTL_RCGCADC_R;
    ADC0_PC_R = 0x01; // 7) configure for 125K
    ADC0_SSPRI_R = 0x0123; // 8) Seq 3 is highest priority
    ADC0_ACTSS_R &= ~0x0008; // 9) disable sample sequencer 3
    ADC0_EMUX_R &= ~0xF000; // 10) seq3 is software trigger
    ADC0_SSMUX3_R = (ADC0_SSMUX3_R&0xFFFFFFFF)+0x5 // 11) Ain9 (PE4)
    ADC0_SSCTL3_R = 0x0006; // 12) no TS0 D0, yes IE0 ENDO
    ADC0_IM_R &= ~0x0008; // 13) disable SS3 interrupts
    ADC0_ACTSS_R |= 0x0008; // 14) enable sample sequencer 3
}
```




Book shows Ain9=PE4 Lab 8, 9, 10 use Ain5=PD2

ADC on TM4C123




```
//-----ADC_InSeq3-----  
// Busy-wait analog to digital conversion  
// Input: none  
// Output: 12-bit result of ADC conversion  
uint32_t ADC0_InSeq3(void){  
    uint32_t data;  
    ADC0_PSSI_R = 0x0008;  
    while((ADC0_RIS_R&0x08)==0){};  
    data = ADC0_SSFIFO3_R&0xFFF;  
    ADC0_ISC_R = 0x0008;  
    return data;  
}
```



4) ADC Data to actual length

Use Calibration.xls in your Lab 8
folder! (part C)

- record your ADC raw Data in 3mm, 7mm, 1.1cm, 1.4cm, 1.8cm & then



5) write systick interrupt so that
ADC-in will be called inside handler
instead of being called in main directly

Why?

- more accurate timing
- release CPU from doing useless while Loop

How often?

- 10Hz because of

Nyquist Theorem

How?

- initialize: Look at your Lab 6 code!
- in your systick_handler:

PFI ^ = 0x02; // toggle LED for TexacDisplay

MailValue = ADC_in(); // MailValue

MailStatus = 1; // Mail status is a global variable

is a global variable
for main


- in your main, instead of calling main:

```
while(1) {  
    while(MailStatus == 0) {};  
    PF3 ^ = 0x 08;  
    mailstatus = 0; // indicate mail is read  
    Position = Convert(MailValue);  
  
    LCD_OutFix(Position);  
}
```

Verify: connect your PF1 to PD3
& use Texas-Display!

6) measure accuracy:

- Measure couple location & record actual position & measured position by ADC
- calculate error & average accuracy in Ch14 cbook:



DONE !!